

Televés

IEC TV konektori
4130 muški
4131 ženski

UPUTSTVO za montažu

